

AMERICAN NATIONAL STANDARD

ANSI/ASSE Z9.11 – 2016 Laboratory Decommissioning

ANSI/ASSE Z9.11 - 2016





This is a preview of "ANSI/ASSE Z9.11-2016". Click here to purchase the full version from the ANSI store.

ANSI® **ANSI/ASSE Z9.11 – 2016**

American National Standard

Laboratory Decommissioning

Secretariat

American Society of Safety Engineers 520 N. Northwest Highway Park Ridge, Illinois 60068

Approved December 23, 2015

American National Standards Institute, Inc.

American National Standard

Approval of an American National Standard requires verification by ANSI that the requirements for due process, consensus, and other criteria for approval have been met by the standards developer. Consensus is established when, in the judgment of the ANSI Board of Standards Review, substantial agreement has been reached by directly and materially affected interests. Substantial agreement means much more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered, and that a concerted effort be made toward their resolution. The use of American National Standards is completely voluntary; their existence does not in any respect preclude anyone, whether he/she has approved the standards or not, from manufacturing, marketing, purchasing, or using products, processes, or procedures not conforming to the standards. The American National Standards Institute does not develop standards and will in no circumstance give an interpretation of any American National Standard. Moreover, no person shall have the right or authority to issue an interpretation of an American National Standard in the name of the American National Standards Institute. Requests for interpretation should be addressed to the secretariat or sponsor whose name appears on the title page of this standard.

Caution Notice: This American National Standard may be revised or withdrawn at any time. The procedures of the American National Standards Institute require that action be taken periodically to reaffirm, revise, or withdraw this standard. Purchasers of American National Standards may receive current information on all standards by calling or writing the American National Standards Institute.

Published February 2016 by

American Society of Safety Engineers 520 N. Northwest Highway Park Ridge, Illinois 60068 (847) 699-2929 • www.asse.org

Copyright ©2016 by American Society of Safety Engineers All Rights Reserved.

No part of this publication may be reproduced in any form, in an electronic retrieval system or otherwise, without the prior written permission of the publisher.

Printed in the United States of America

Foreword (This Foreword is not a part of American National Standard Z9.11-2016.)

Modern laboratory facilities may require periodic renovation or even demolition. Before this can be done safely, the facility must be properly decommissioned in order to prepare it for future occupancy. Both the past use and the prospective function of the space will determine the degree of decommissioning. Therefore, a risk-based approach is necessary to control the parameters of the decontamination process – whether the space will be used as another research laboratory or a non-laboratory space, such as a daycare center or office suite.

The Z9.11 subcommittee was chartered to develop guidelines on decommissioning a research laboratory whenever laboratory spaces are to be renovated or demolished, with a special emphasis on the risk assessment process. This is difficult because of the wide variety of materials, chemicals, equipment and processes that are used and conducted in laboratories. Thus, the focus of this standard is to provide a process for determining what actions are necessary to properly decommission a laboratory given its current and potential future use. The standard also provides a model to follow to accomplish the desired result. Where possible, specific guidance is provided as an example. The following American National Standard is the product of this subcommittee's efforts.

Decommissioning a work site requires standardized processes, strategies and validation methods for rapid screening and characterization of hazardous debris and other regulated waste streams and for compliance with hazardous waste regulations. Baselines for decommissioning must be established for the types of contamination that will be evaluated, the types of equipment that will be tested, safe levels of contamination and how far to look for contaminants. Strategies to minimize generation of regulated wastes, to encourage onsite treatment and decontamination technologies and to maximize recycling/recovery of materials from debris must also be considered. Other essential factors to consider are a cost-benefit analysis of decontamination and recycling versus disposal without decontamination, and the life cycle design of laboratories and selection of construction materials to facilitate eventual deconstruction.

How to Read This Standard

The standard is presented in a two-column format. The left column presents the requirements of the standard; the right column provides clarification and explanation of the requirements plus "how to comply" information.

This standard also contains Appendices, which are informative and are not considered a mandatory part of this standard.

This standard is not meant to be all encompassing. Rather, it establishes minimum acceptable criteria for completing the decommissioning process and documenting the necessary information for regulatory and historical purposes. It is somewhat general in nature so that it can be applied to any research laboratory. We hope, however, that future versions will continue to expand and amplify these concepts as additional experience is gained.

Suggestions for improvement of this standard are welcome. They should be sent to the American Society of Safety Engineers, 520 N. Northwest Highway, Park Ridge, Illinois 60068.

This standard was processed and approved for submittal to ANSI by the Z9 Accredited Standards Committee on Health and Safety Standards for Ventilation Systems. Committee approval of the standard does not necessarily imply that all committee members voted for its approval. At the time it approved this standard, the Z9 Committee had the following members:

Theodore Knutson, MS, P.E., Chair Geoffrey Raifsnider, P.E., Vice Chair Ovidiu Munteanu, Secretary Timothy R. Fisher, CSP, CHMM, ARM, CPEA, Assistant Secretary Jennie Dalesandro, Administrative Technical Support

Organization Represented

American Foundry Society American Industrial Hygiene Association American Society of Heating, Refrigeration & A/C American Society of Safety Engineers

Burton, D. Jeff Figueroa, Crescente Global Finishing Solutions

Knutson Ventilation Inc.

National Association of Metal Finishers

National Institutes of Health (NIH)
National Institute for Occupational Safety & Health
Northwest Occupational Health & Safety
Paulson, Kathleen
People, Property & Environmental Protection, Inc.
Price, John
Robson Forensic, Inc.
Saint-Gobain Abrasives
Sheehy, John
Thermo Fisher Scientific

Non-Voting Members:

Lee Hathon John H. Llibre Don R. Scarbrough

Subgroup Z9.11 had the following members:

Farhad Memarzadeh, Ph.D., P.E. (Chair)
Lou DiBerardinis, CIH, CSP (Vice Chair)
Rateb (Boby) Abu-Eid, Ph.D.
Sheri Bernstein
Chad Dorgan, Ph.D., P.E., LEED AP BD+C
William K. Floyd
Bob Hawley Ph.D., RBP, SM (NRCM), CBSP
Robert Kleinerman, MPH, CIH
Pamela A. Kostle, CIH
Ed Levesque, CIH
Jon P. Lillemoen, CIH
William Martin, CSP
Nancy Newman
Michael Norato, Ph.D.

Name of Representative

Robert Scholz Lou DiBerardinis, CIH, CSP, MIT Thomas C. Smith Paul Osley, P.E., CSP, CIH, CHMM Jeffrey Nesbitt, CSP, CIH D. Jeff Burton, CIH, CSP, P.E. Crescente Figueroa, Ph.D., CIH Geoffrey Raifsnider, P.E. Brian Schadrie, P.E. Theodore Knutson, MS, P.E. Gerhard Knutson, Ph.D., CIH Kyle Hankinson Kenneth Hankinson Farhad Memarzadeh, Ph.D., P.E. Michael G. Elliott, Ph.D., P.E., CIH Neil McManus, CIH, ROH Kathleen Paulson, P.E. Steven Crooks, CIH, CSP John Price, CIH, CSP Ronald D. Schaible, CSP, CIH Ellen Pomer John Sheehy, Ph.D. Mark Rollins, CIH, CSP

Contents	SE	CTION	PAGE
	1.	Executive Summary	8
	2.	Scope	9
	3.	Definitions	10
	4.	Applicability and Exceptions	19
	5.	Overview	
		5.1 Decommissioning Sequence	
		5.2 Decommissioning Process Flow	
		5.3 Critical Team Member Roles and Responsibilities	25
	6.	Needs Analysis and Scoping	28
		6.1 Assessment	
		6.2 EH&S Decommissioning Assessment Plan	29
		6.3 EH&S Decommissioning Scope of Work	
		6.4 Needs Analysis and Scoping	
		, 1 5	
	7.	Risk Assessment and Characterization	36
		7.1 Overview	
		7.2 Risk Assessment/Characterization Process	
		7.3 Field Sampling Plan (FSP)	
		7.4 Quality Assurance Project Plan	
		7.5 Review and Approve Sampling and Analysis Plan (SAP)	
		7.6 Perform Sampling and Analysis	
		7.7 Data Review	
		7.8 Risk Assessment Report	
		7.9 Common Laboratory Contaminants	
		·	
	8.	Guideline for Implementing Remediation and Mitigation Process	
		8.2 Starting Activities	
		8.3 Remediation Plan Process	
		8.5 Environmental, Health and Safety Plan	
		8.6 Remediation and Mitigation Work Flow	
		8.7 Remediation Plan: Inputs and Relationships	51
	9.	Verification	
		9.1 Verification of Decontamination	52
		9.2 Verification of Sampling and Analysis	54
		9.3 Verification of Sample Analysis	55
		9.4 Verification of Compliance to Scope	55
		9.5 Verification of Compliance to Regulations	
	10.	. Documentation	57
		10.1 Decommissioning Plan	57
		10.2 Decommissioning Report	
		10.3 Statement of Risk	

This is a preview of "ANSI/ASSE Z9.11-2016". Click here to purchase the full version from the ANSI store.

Appendices:

Α	Typical Decontamination and Disposal Processes	59
В	Mercury: Air Concentrations of Inorganic Mercury Table of	
	Background, Action and Regulated Levels	60
С	Guide for Identifying Areas of Potential Chemical Contamination	61
D	Hazard Ranking	62
Ε	Guidelines for Decommissioning of the Biologically Contaminated Systems.	64
F	Criteria for Levels of Decommissioning Assessment and Scope	66
G	Phases in a Decommissioning Project	68
Н	Checklist for Common Laboratory Contaminants	70
1	Crisis Management Planning for Decommissioning Projects	72
J	Index of Acronyms	. 77
K	Suggested Further Reading	78

AMERICAN NATIONAL STANDARD Z9.11-2016

AMERICAN NATIONAL STANDARD Z9.11 LABORATORY DECOMMISSIONING

STANDARD REQUIREMENTS

EXPLANATORY INFORMATION

(Not part of American National Standard Z9.11)

1. EXECUTIVE SUMMARY

Decommissioning is a process to ensure a facility and its associated infrastructure meet environmental health and safety requirements for its next use. Its next use could be similar to its previous use as a laboratory or it could be vastly different, such as a daycare center. Construction or renovation is also defined as next use. For research laboratories, a risk-based approach to decommissioning is recommended. This process assumes that laboratories are inherently safe environments where hazardous materials are used with safeguards that protect human health and the environment, and that extraordinary decommissioning methods may only be necessary for situations that present unusual risks.

This standard provides a strategy to perform a risk assessment of a research space and to make that space safe and ready for the demolition worker to begin work and/or for the next occupant to use the space. Additionally, consideration is given to appropriate management of the waste materials through a remediation plan process and a description of remediation plan elements.

This standard addresses approaches for dealing with common contaminants and waste management and provides details for managing the presence of extremely hazardous materials or exceptional circumstances.

This standard provides general guidance to develop a decommissioning plan that meets the needs of the institution.

Stakeholders include project managers and others who may not be familiar with the

regulations. Recommendations are included for risk assessment resource materials that address risks not specifically covered in the standard.

This standard:

- Provides an overarching roadmap for the research laboratory decommissioning process that can assist an institution in developing its own decommissioning plan;
- Assists in determining levels of risk assessment that are needed for a research laboratory decommissioning;
- Provides a standard generic enough to develop a decommissioning plan for a research laboratory of any size and provides references, tables and other resource information to assist the user in assessing the risk level of the project;
- Identifies tools that need to be developed to decommission a research laboratory; and
- Identifies roles and responsibilities for stakeholders.

The criteria contained herein shall be supplemented, expanded or consolidated as required to adapt to the specific decommissioning effort, the organization and the specific regulatory and policy requirements which may apply in each case.

2. SCOPE

Hazardous materials identified or generated from the facility decommissioning process are subject to intense regulation and present significant potential liabilities. The need to improve characterization and management of these wastes is a primary driver for development of improved decommissioning strategies.

Research laboratory facilities and their associated spaces pose unique decommissioning concerns because of the nature of the use of workspace. The intent of this standard is to address a decommissioning