

Contents	Page
1 Introduction.....	1
2 Scope	1
3 Basic considerations	1
4 Rejection elastic expansion values.....	2
5 Sources of K factors	2
6 Determination of rejection elastic expansion limits.....	4
6.1 Indirect method.....	4
6.2 The Bach formula	4
6.3 The Clavarino formula	4
6.4 Example of determining the elastic expansion rejection limit	5
6.5 Simplified way to determine the REE limit.....	6
6.6 K factors and REE limits in Table 1	6
7 References	6

Tables

Table 1—Standard elastic expansion and K factor limits	7
1a—Industrial high pressure seamless steel cylinders	7
1b—Medical high pressure seamless steel cylinders	8
1c—High pressure seamless steel tubes	9
Table 2—Solutions of Bach stress formula	10

Appendices

Appendix A—Flow chart for service life control (Informative).....	11
Appendix B—DOT Hazardous Materials 49 CFR 173.302a(b) special filling limits (Normative).....	12
Appendix C—TC Requirements (Normative)	14