

This is a preview of "ISO 6750-1:2019". Click here to purchase the full version from the ANSI store.

First edition
2019-10

Earth-moving machinery — Operator's manual —

Part 1: Contents and format

*Engins de terrassement — Manuel de l'opérateur —
Partie 1: Présentation et contenu*



Reference number
ISO 6750-1:2019(E)

© ISO 2019

This is a preview of "ISO 6750-1:2019". Click here to purchase the full version from the ANSI store.



COPYRIGHT PROTECTED DOCUMENT

© ISO 2019

All rights reserved. Unless otherwise specified, or required in the context of its implementation, no part of this publication may be reproduced or utilized otherwise in any form or by any means, electronic or mechanical, including photocopying, or posting on the internet or an intranet, without prior written permission. Permission can be requested from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
CP 401 • Ch. de Blandonnet 8
CH-1214 Vernier, Geneva
Phone: +41 22 749 01 11
Fax: +41 22 749 09 47
Email: copyright@iso.org
Website: www.iso.org

Published in Switzerland

This is a preview of "ISO 6750-1:2019". Click here to purchase the full version from the ANSI store.

Contents

	Page
Foreword	iv
Introduction	v
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 General information for operator's manuals	4
4.1 General information	4
4.2 Machine configurations	4
4.3 Attachments, tools, additional equipment	5
4.4 Units of measurement	5
4.5 Original language and translations	5
4.6 Graphical symbols	5
4.7 Meaning of audible and visual signals on the machine	5
4.8 Basic information	5
5 Content of operator's manuals	5
5.1 General	5
5.2 Identification of the operator's manual	5
5.3 Table of contents	6
5.4 Identification of the machine	6
5.5 Introduction	7
5.6 Safety information	8
5.6.1 Residual risks	8
5.6.2 Safety alert symbol	8
5.6.3 Signal words	8
5.6.4 Safety messages	8
5.6.5 Machine safety labels	9
5.7 Operation	11
5.7.1 General	11
5.7.2 Controls and displays	11
5.7.3 Operating instructions	11
5.8 Troubleshooting	11
5.9 Maintenance and adjustments	12
5.9.1 General	12
5.9.2 Precautions prior to maintenance	12
5.9.3 Maintenance instructions for the operator	12
5.10 Spare parts list	13
5.11 Preservation and storage	13
5.11.1 General	13
5.11.2 Prior to long-term storage	13
5.11.3 After long-term storage	13
5.12 End of service life information	13
5.13 Specifications — Machine technical data	14
Annex A (normative) Basic information for inclusion in operator's manual	15
Annex B (informative) Presentation and format of the operator's manual — Recommendations	18
Annex C (informative) Electronic media	21
Bibliography	23

This is a preview of "ISO 6750-1:2019". Click here to purchase the full version from the ANSI store.

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The procedures used to develop this document and those intended for its further maintenance are described in the ISO/IEC Directives, Part 1. In particular, the different approval criteria needed for the different types of ISO documents should be noted. This document was drafted in accordance with the editorial rules of the ISO/IEC Directives, Part 2 (see www.iso.org/directives).

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights. Details of any patent rights identified during the development of the document will be in the Introduction and/or on the ISO list of patent declarations received (see www.iso.org/patents).

Any trade name used in this document is information given for the convenience of users and does not constitute an endorsement.

For an explanation of the voluntary nature of standards, the meaning of ISO specific terms and expressions related to conformity assessment, as well as information about ISO's adherence to the World Trade Organization (WTO) principles in the Technical Barriers to Trade (TBT) see www.iso.org/iso/foreword.html.

This document was prepared by Technical Committee ISO/TC 127, *Earth-moving machinery*, Subcommittee SC 3, *Machine characteristics, electrical and electronic systems, operation and maintenance*.

This document cancels and replaces the third edition (ISO 6750:2005), which has been technically revised. The main changes compared to the previous edition are as follows:

- the required contents of the operator's manual of earthmoving machinery has been updated;
- additional information on the use of electronic media for the operator's manual is now provided.

A list of all parts in the ISO 6750 series can be found on the ISO website.

Any feedback or questions on this document should be directed to the user's national standards body. A complete listing of these bodies can be found at www.iso.org/members.html.

This is a preview of "ISO 6750-1:2019". Click [here](#) to purchase the full version from the ANSI store.

Introduction

Operators need to have available an operator's manual giving guidance for the correct use and maintenance of the machine and its equipment and attachments. It is accordingly expected that such an operator's manual be clear and simple to understand, that it contains warnings for reasonably foreseeable hazards as well as definitions of terms, and that the units, symbols and pictorials used comply with the relevant International Standards.

This edition has been prepared such that it is aligned with the similar technical area covered by ISO 3600.